


SPIDER-MAN® WEBWORLD RACERS FACE-OFF

- 1 Place launcher on floor and lock bikes into launcher.




CAUTION:


Hair entanglement may result if child's hair comes in contact with moving parts of toy. Adult supervision is required. While in operation the wheel may cause friction burns. Keep hands away from moving wheel.

2

- Holding launcher handle, turn the crank about 10 times.



- 3 Press the button on the launcher to watch the bikes go screaming across your floor!



This launcher is compatible with all **SPIDER-MAN WEBWORLD RACERS!**

Collect them all!
NEW GOBLIN™ Spider Slayer
SPIDER-MAN Goblin Stomper
SPIDER-MAN Street Spider Motorcycle
 Each sold separately.



Not suitable for children under 3 years because of small parts — choking hazard.

COLUMBIA PICTURES
© 2006 COLUMBIA PICTURES INDUSTRIES, INC. ALL RIGHTS RESERVED.

SPIDER-MAN
 MERCHANDISING

Spider-Man and all related characters and the distinctive likeness thereof: TM & © 2007 Marvel Characters, Inc.
 Spider-Man 3, the Movie: TM & © 2007 Columbia Pictures Industries, Inc. All rights reserved.
 ®* and/or TM* & © 2006 Hasbro. All Rights Reserved.
 TM & © denote U.S. Trademarks.

P/N: 6646250000

